

## Serial Number locations for Air Powered Fluid Handlers

### MODEL AH-15

Located at the bottom near the handle  
(located on the frame)



### MODEL OH-15

Located at the bottom near the handle  
(located on the frame)