

Serial Number locations for cylinder style lifts

MODEL WL-20 & WL-30

Located on top of cylinder



MODEL TNT-550

Located on top of cylinder



MODEL PM-350

Located on top of cylinder



MODEL BF-100

Located on top of cylinder



MODEL TSJ-55

Located on top of cylinder

